

PRESSALIT.

Product	Toilet seat Dania with cover, 4"/2" raised
Item number	R35000
	VVS:615689000
	NRF:6190585
	EAN:5708590070544
	HMI: 1818
	NBS:N13:300
Color	White
Product description	Toilet seat, Dania, with stabilizing buffers, w/cover, slanting 4"/2", incl. splashguard. With raised cross bar hinge
	Toilet seat, Dania, with stabilizing buffers, w/cover, slanting 4"/2", incl. splashguard With raised cross bar hinge
Product capacity	This product has been tested statically up to 495 lbs. As the European standard for technical aids for disabled, EN 12182:2012, requires a static test with safety factor 1.5, the nominal maximum load for this product is therefore 330 lbs.
Materials	Seat/cover: Thermoset plastic (urea) Strap: Stainless steel V2A Raiser: Nylon (PA) Special buffer: ABS-plastic
Ergonomy	An ergonomically designed toilet seat suitable for most people. Sideways transfer is easy because the seat is flat. The cover is comfortable to sit on, and when set in the upright position it provides good back support. The slanted design makes it easier to sit down and stand up from toilets of normal height.
Warranty	Your Pressalit toilet seat is subject to a 10-year product warranty against presentation receipt. You should contact the dealer or store where you purchased the seat in the event of a complaint. In the event of complaints about defective materials and/or manufacturing defects and/or functional limitations ascertained within a 10-year period, following proper use and cleaning of the toilet seat (we reserve the right to examine the toilet seat at our factory), Pressalit will deliver spare parts or replace the toilet seat by an identical or similar model. If the color is no longer available, Pressalit reserves its right to replace the toilet seat by a similar model in the color white. Upon replacement or delivery of a spare part, the warranty period will not be extended nor renewed. If replacement is not possible, Pressalit may instead refund the purchase price.



PRESSALIT.

Use a mild soap solution to clean the toilet seat. Please take care that the seat and hinges are not left damp. For disinfecting the seat, e.g. ethanol 85% can be used. Make sure that the product is wiped down with a soft rag wrung out in clear water a
dried off with a soft, dry cloth immediately after disinfection. Avoid contact of the seat and hinges with abrasive, corrosive or chlorine-based cleaners, as these may cause damage or lead to flash rust. Therefore, when cleanin the bowl, make sure that the seat and cover are kept in an upright position until all cleaning agent has been flushed away.
с tl

pressalit.com

Pressalit A/S Pressalitvej 1 DK-8680 Ry Tel.: +45 8788 8788 Fax: +45 8788 8789 E-mail: pressalit@pressalit.com