

PRESSALIT.

Product	Lift for countertop, manually height adjustable
Item number	RK1114
	EAN:5708590292793 HMI: 54803
Product description	The name INDIVO relates to the individual configuration of the products. Manual lift for countertop Lift for countertop, with a crank handle Including 5 brackets Lengths from 94.5"-118.1". Height adjustable 11.8". Incl. mounting kit for brick wall Please state desired length when ordering
Adjustability	Height adjustable
Product capacity	Maximum load (evenly distributed): 220 lbs including countertop.
Materials	Material: Telescopic leg: Aluminium, ABS plastic Cross braces: Aluminium Brackets: Steel Crank handle: Steel Surface treatment: Brackets: Powder lacquered (grey RAL 9006)
Ergonomy	Kitchen countertops which can be adjusted in height using a crank handle are the budget solution for kitchens catering to both seated and standing users. These are most commonly used in kitchens which do not require frequent, daily adjustment.
Features	Manual lifts are adjusted in height using a crank handle. They can be used with countertops, with or without an edge. The crank handle socket can be positioned anywhere along the front edge, except under a sink or hob. Lifts can be adapted to most standard kitchen components. Lifts are available for countertops of any length between 23.6" and 118.1". Height adjustable 11.8".



PRESSALIT.

Product	Lift for countertop, manually height adjustable
ltem number	RK1114
Warranty	Pressalit makes a commitment to remedy material and manufacturing defects for a period of three years from the invoicing date.
Cleaning	This product should be cleaned with hot water or a mild cleaning solution. Do not use chlorine based, corrosive or abrasive cleaners as it may result in the surface being damaged.
	The following cleaning agents have been tested by Pressalit and may be used, as long as they are diluted according to the instructions on the container.
	DISINFECTANTS: Clinimax Difficil-S Erisan OXY+ Sprit (husholdningssprit) Suma Bac D10 Virkon Rodalon Desinfektionsspray Lysoformin Spezial CaviCide Sufanios Premium Tvättsprit 70%
	NON-DISINFECTANTS: Suma Star free D1 Taski 100 Taski 200 Milizid Citro
	The product must be wiped down with a soft rag wrung out in clear water immedia after cleaning, as some materials may otherwise be discolored and stained, and the surface coating may deteriorate.
	DECALCIFICATION OF ALUMINUM PARTS: Pressalit recommends that water deposits (Calcium, lime etc.) be removed from w tracks and other aluminum parts using a solution of three parts of 30% acetic acid seven parts tap water. When the aluminum parts have been washed down with th solution, the parts should be wiped over with a damp cloth wrung out in plain wate



PRESSALIT.

Product	Lift for countertop, manually height adjustable
ltem number	RK1114

pressalit.com

Pressalit A/S Pressalitvej 1 DK-8680 Ry Tel.: +45 8788 8788 Fax: +45 8788 8789 E-mail: pressalit@pressalit.com

