



PRESSALIT®

Product	MATRIX LARGE sink with overflow
Item number	R2030000
Color	VVS:636858100 NRF:6132505 EAN:5708590325088 HMI: 82612 NBS:N13:30,335 White
Product description	<p>MATRIX is a series of sinks, most of them are designed by Pressalit. MATRIX SMALL and CURVE sinks fit onto PLUS, SELECT and VALUE sink brackets, whereas MATRIX MEDIUM and ANGLE are tailor made to fit specific brackets.</p> <p>MATRIX LARGE vanity sink, 35.4" x 19.3" x 5.1" with two integrated grab handles on the front edge and two grab handles at the sides. With tap hole diameter 1.4", with overflow, incl. drain fitting. The sink has raised edges, preventing water from running over the back or down the outer sides.</p> <p>Materials: Cultured marble with a high-polished, nonporous sanitary gel coating. Suitable for R2015 height adjustable sink supports.</p>
Product capacity	440 lbs.
Materials	Cultured marble with a high-polished, nonporous sanitary gel coating.
Warranty	Pressalit makes a commitment to remedy material and manufacturing defects for a period of five years from the invoicing date.



PRESSALIT®

Product	MATRIX LARGE sink with overflow
Item number	R2030000
Cleaning	<p>For cleaning the wash basin, use hot water and a mild soapy cleaning agent. Make sure that the product is wiped down with a soft rag wrung out in clear water immediately after cleaning.</p> <p>For disinfecting the wash basin, the following agents can be used:</p> <ul style="list-style-type: none">Sodium hydroxide 5%Acetic acid solution 10%Ethanol solution 70%Sodium hypochlorite 5%, active chlorineSodium chloride 170g/l, diluted to 50%. <p>Make sure that the product is wiped down with a soft rag wrung out in clear water immediately after disinfection.</p> <p>NB! Do not use abrasive cleaning agents, as this will cause damage to the surface of the wash basin.</p>

pressalit.com

Pressalit A/S
Pressalitvej 1
DK-8680 Ry
Tel.: +45 8788 8788
Fax: +45 8788 8789
E-mail: pressalit@pressalit.com

PRESSALIT®