




# PRESSALIT®

<b>Product</b> <b>Item number</b>	PLUS backrest, fixed height R6310000
<b>Color</b>	VVS:777538000 NRF:6311138 EAN:5708590314211 HMI: 71811 NBS:N13:426 FDA:INN/D135865 White
<b>Product description</b>	 PLUS backrest 11.5". For fixed mounting. Incl. mounting kit for brick wall.  PLUS backrest 11.5". For fixed mounting. Incl. mounting kit for brick wall.
<b>Adjustability</b>	Fixed mounting
<b>Product capacity</b>	Maximum load: 220 lbs.
<b>Materials</b>	The backrest is made of polyurethane (PU) foam which is covered with a moulded coated surface that is protected using a clear PU lacquer.
<b>Ergonomy</b>	Soft and slip-resistant material that has a warm feel.
<b>Warranty</b>	Pressalit makes a commitment to remedy material and manufacturing defects for a period of five years from the invoicing date.



# PRESSALIT®

<b>Product</b>	PLUS backrest, fixed height
<b>Item number</b>	R6310000
<b>Cleaning</b>	<p>This product should be cleaned with hot water or a mild cleaning solution. Do not use chlorine based, corrosive or abrasive cleaners as it may result in the surface being damaged.</p> <p>The following cleaning agents have been tested by Pressalit and may be used, as long as they are diluted according to the instructions on the container.</p> <p><b>DISINFECTANTS:</b> CaviCide</p> <p>The product must be wiped down with a soft rag wrung out in clear water immediately after cleaning, as some materials may otherwise be discolored and stained, and the surface coating may deteriorate.</p> <p><b>DECALCIFICATION OF ALUMINUM PARTS:</b> Pressalit recommends that water deposits (Calcium, lime etc.) be removed from wall tracks and other aluminum parts using a solution of three parts of 30% acetic acid to seven parts tap water. When the aluminum parts have been washed down with this solution, the parts should be wiped over with a damp cloth wrung out in plain water.</p>

[pressalit.com](http://pressalit.com)

Pressalit A/S  
Pressalitvej 1  
DK-8680 Ry  
Tel.: +45 8788 8788  
Fax: +45 8788 8789  
E-mail: [pressalit@pressalit.com](mailto:pressalit@pressalit.com)

## PRESSALIT®